

Owner's Manual




Picture B: Before installation, firstly, to open a hole Φ52mm(2") of the panel, make sure there is a space with (55mm backyard of panel) as well.



Picture D: Put the gauge in the hole and screw down.

Picture E:Size and annotations



Connection

1 Black: Ground(-)
2 Red: 9-32VDC(+)

3 Blue: Signal

4 Yellow: Backlight 5 White: Adjust

Technical parameters:

Operatingvoltage: 9~32VDC Operating current: ≤100mA

Operating temperature: -20~ 70°C Storage temperature: -30~ 80°C

The white wire touches the negative pole shortly, change the backlight color: Backlight changed in sequence: red (default) \rightarrow green \rightarrow blue \rightarrow white \rightarrow yellow \rightarrow cyan \rightarrow Purple \rightarrow (automatic). Automatic: Automatically switch the backlight color every 1 minute, Cycle switch according to the above sequence.

If it is a voltmeter, no external signal line is required.